









BC-PM3  BC3


 TB  



 OSC  AUX  
MST 




0 1 2 3 4 5 6  
MST

 AFL


 AUX 3


CUT 


 TB 

 OSC  AUX  
MST 

0 1 2 3 4 5 6  
MST

 AFL

 AUX 4

CUT 

 TB 

 OSC 


 MONO  CUE  
MST 

0 1 2 3 4 5 6  
MST

 AFL

 CUE

CUT 

 TB



 OSC



 LINE



 OFF


 PGM

OUTPUT

 INSERT  
POST FDR 


 PGM  
INSERT 

 TRIM ON 



0 2 4 6  
±dB

L-R  
TRIM



dB

10

5

0

5

10

15

20

25

30

40

50

60

85

∞

