







BC-IM4  BC3

GR 1-2  

GR 3-4 

GR 5-6 


GR 7-8 

 PGM



**Gain and Routing:**

- MIC:** 28-70 dB knob, PAD button
- LINE:** 10-20 dB knob, P48 button, LINE button
- AUX1-4:** 0-6 knob, PRE buttons, CH-OUT button
- LEVEL:** 0-6 knob, CUE button, POST button
- HPF:** 40-300 Hz knob, N-MINUS button
- THR:** 10-30 dB knob, AUTOGAIN ON button
- REL:** 0.1-1 knob, 5s
- RAT:** 1.1-1.7 knob, 8 LIM
- HI:** 4-15 knob
- MID2:** 4-15 knob, EQ button
- MID1:** 0-4 knob, EQ button
- LOW:** 4-15 dB knob, INS button
- PAN:** L-C-R knob, PAN button

**Dynamic Processing:**

- ATT:** 0.1-1 knob, 5ms
- EXP:** 10-40 dB knob, EXP-ON button
- DYN:** 

**Other Controls:**

- GR dB:** 1-20 color-coded bar
- FILT:** 
- CUT:** 

 CH 24 ON  START

 FDR OPEN  PS  PFL

**Vertical Scale:**

15 dB, 10, 5, 0, 5, 10, 15, 20, 25, 30, 35, 40, 50, 60, 75, ∞

