

BC-TB04b

BC4

SEL3

SRC 17

SRC 18

SRC 19

SRC 20

SRC 21

SRC 22

SRC 23

SRC 24

SEL3

Yellow indicator lights

EXTENSION SOURCE

INT-MIC

EXT-MIC

ON

LISTEN

EXT-LINE DETECT

LISTEN ON

EXTGMIC

ON

LISTEN INT-BUS

LISTEN

CUT

LISTEN-SYSTEM

TO PFL BUS

AUTO DIM

OSC

OSC LEVEL

100 1k 10k 15k Hz

OSC

CUT

LEVEL POT ON

AUX CUE

GROUP PGM

CH

Yellow buttons

ON AIR

TB EXT1

+

TB EXT2

+

TB AUX

+

TB GRP

+

TB CH

+

TB TELCO

+

TB STU

+

ALTERNATE

+

TB ALL

+

ON VG 5

ON VG 6

dB

10

5

0

5

10

15

20

25

30

40

50

60

85

∞