

BC 1
TB



act-audio

GAIN



0 1 2 3 4 5 6

TB

REMOTE

REMOTE

0 1 2 3 4 5 6

LISTEN

TB-BUS

10kHz

0 1 2 3 4 5 6

FREQ

1kHz

100Hz

0 1 2 3 4 5 6

LEVEL

UNCAL

ON

OSC

OSC TO

GR/AUX

OSC TO

PGM



STU-SRC



AUX4



AUX3



AUX2



AUX1



MIX

0 1 2 3 4 5 6

TB

DIM

0 1 2 3 4 5 6

STU-PHONES



0 1 2 3 4 5 6

TB

TB

DIM

0 1 2 3 4 5 6

STU-SPEAKERS

AUTOCUT

CUT

MIC

MIC ON



LINE ON



ON AIR



ENABLE

TB

GR/AUX

GR/AUX

PGM

TB PGM

CPLE TO STUDIO

TELCO

TB TELCO

LINE

LINE

TB

LISTEN

LISTEN

STU

TB STUDIO

