

BCI

adt-audio

MIC (P48) 33 40 48 56 70 dB

LINE 4 9 20 20 ±dB

HPF 40 70 140 200 270 300 Hz

HI 4 9 15 15 ±dB

MID2 1 2.5 6 10 kHz

MID1 4 9 15 15 ±dB

LOW 4 9 15 15 ±dB

AUX 1 0 1 2 3 4 5 6 CUT ↑

AUX 2 0 1 2 3 4 5 6 CUT ↑

AUX 3/4 PAN 3 4

LEVEL 0 1 2 3 4 5 6 CUT ↑

FRONT 1 F/S PAN

LCR PAN L R

Buttons: PAD (-30dB), LINE, ∅, FILT, 15kHz, 10 kHz, INS, 60Hz, 100 Hz, EQ, PRE, PRE, PRE, Σ1, Σ2, Σ3, Σ4, PK, PS, CUT, PFL

